

Televes®



coax
DATA
1Gbps HDTV

EN CoaxManager™
User Guide

Content Index

Important safety instructions.....	4
General installation conditions.....	4
How to use the equipment safely.....	4
Electrical safety symbols.....	4
Introduction.....	5
Application Description.....	5
Features.....	5
System Requirements	5
Supported CoaxDATA Devices.....	5
Installing CoaxManager Application.....	6
Connecting CoaxDATA Modem to CoaxManager	7
Device Configuration.....	8
MDU Configuration.....	9
Select Transmission medium.....	10
Transmission Mask.....	11
Writing Device Settings	12
Checking Devices Network.....	13
Device Info.....	13
CCO Info.....	14
Network Topology.....	14
Generating traffic to verify network links	15
Generating Reports for Checking Network State.....	16
Setting QoS parameters (Advanced User)	18
Default Priorities.....	18
Priority Levels Assignment.....	19
TTL - Time to Live.....	19
Buffer Allocation, Priority Thresholds.....	20
Bandwidth Limit.....	21
Bandwidth Limit with QoS.....	21
Setting Advanced Configuration	23
IGMP options.....	23
Number of Users per Slave.....	25
Network Mitigation.....	25
Factory Defaults Button.....	27
Advanced Power Management.....	27
Advanced MME Features.....	27



Important safety instructions

General installation conditions

- Before handling or connecting the equipment, please read this manual.
- In order to reduce the risk of fire or electric shock, do not expose the equipment to rain or moisture.
- Do not take the cover off the equipment without disconnecting it from the AC power.
- Do not obstruct the equipment's ventilation system.
- Please allow air circulation around the equipment.
- The equipment must not come into contact with water or even be splashed by liquids. Do not place containers with water on or near the equipment if it is not adequately protected.
- Do not place the equipment near sources of heat or in excessively moisture conditions.
- Do not place the equipment where it may be affected by strong vibrations or knocks.

EN

How to use the equipment safely

- The powering supply of this product is: 100-264 Vac~ 50/60 Hz.
- If any liquid or object falls inside the equipment, please contact a specialized technician.
- To disconnect the equipment from the mains, pull from the connector, and never pull from the cable.
- Do not connect the equipment to the mains until all the other connections have been made.
- The AC Power socket that is going to be used to connect the equipment should be located nearby and should be easily accessible.

Electrical safety symbols



This symbol indicates compliance with the requirements of CE mark.



This symbol indicates that the equipment is for indoor use only.



This symbol indicates that the equipment complies with the safety requirements for class II equipment.


Introduction

Application Description

CoaxManager™ software allows CoaxDATA™ device configuration, setting different modes of operation, checking installation state and links between devices. CoaxManager™ also allows configuration of QoS parameters, and other options such as activation of low-power modes for energy efficiency,

EN

Features

- ◆ Check coax or PLC installation obtaining **links status and traffic rates** between devices.
- ◆  Create **PDF reports** of network status for later analysis.
- ◆ Allows basic device configuration setting **MxU/HomeNetworking** operating modes.
- ◆ Set **Network password** for create several system networks. You can install up to four masters (each with a different key) on the same coaxial network.
- ◆ Allows configuration of **QoS parameters** supporting four priority levels based on IEEE 802.1Q VLAN tags or IPv4 ToS (Type of Service).
- ◆ Supports **Advanced Features** to configure IGMP, number of users or Low Power Mode.

System Requirements

- ◆ Application works with Windows 2000/XP/Vista/7/8
- ◆ Application works on Mac OS X and Linux Operating systems with virtualization based on Oracle VM VirtualBox software for Windows 2000/XP/Vista/7/8.
- ◆ Application requires installation of additional Winpcap library (<http://www.winpcap.org/install/default.htm>). If library is not installed, CoaxManager automatically install on your PC.
- ◆ System is fully **Plug & Play** and requires no installation of any additional software or drivers.

Supported CoaxDATA Devices


Following CoaxDATA devices are supported by application:

- Ref.7689 CoaxDATA™ 200Mbps-HDTV
- Ref.768973 CoaxDATA™ 200Mbps-HDTV 1xEth
- Ref.769201 CoaxDATA™ 1Gbps-HDTV
- Ref.769202 CoaxDATA™ 1Gbps-HDTV with SFP
- Ref.769203 CoaxDATA™ 1Gbps-HDTV 1XEth

Installing CoaxManager Application


CoaxManager application installed through an executable that guide the user through the installation process.

Language selection: This option selects setup language



EN

Follow installer instructions to complete application installation. Read carefully license before use program and approval before continue.




Once installed application will appear on your desktop the icon below:



Connecting CoaxDATA Modem to CoaxManager

After installing application, when CoaxManager start scan all computer ethernet interfaces trying to find connected devices. In the case of identifying a device already connected, get information associated therewith.



EN

Application provides two combos **NIC Interface** and **Devices** showing interfaces and devices that have been located within these interfaces. When pressed in combo **Devices** updates automatically **Network Devices** list, showing local device (connected directly through ethernet) and all devices that it has located within its network. .

Click on **Connect/Disconnect** Button to select which device you want to configure. Different operations are available :

- **Read Config:** Reads connected device configuration. This operation is performed automatically when connected to a device.
- **Write Config:** Write configuration on connected device. Configuration is changed through tab GUIs.
- **Factory Defaults:** Sets device to factory settings. Be careful with this option since restore to factory configuration causes lose any settings you made on it. This button has the same effect as Factory Defaults button located on the front of the modems.
- **Help:** This manual.

Once connected to device we have access to different tabs that show different information about it.




If you can not connect to device, verify that this is correctly connected via an Ethernet cable. If there is an intermediate switch or other network devices, are configured properly.

Device Configuration

Operation mode setting can be performed through **Configuration tab**, where shows device info and also those fields that configure device access mode, network password or transmission mask.

EN



Device Parameters displays information about device:

- **Firmware Version:** Version Info of Device Firmware.
- **PIB Version:** Device PIB Version (Parameters Information Block) . PIB stores user configuration changes and contains firmware runtime parameters.
- **MAC Address:** Device MAC Address. All Televes MAC Address start with 00:0E:7C hexadecimal values and are registered on IEEE.
- **DAK key (Device Access key):** Key established in the manufacturing process and determines access to devices when it occurs remotely (via coaxial). Knowledge of this key is essential for updating/configuring devices remotely, although default DAK key value is always the same, on manufacturing process, simplifying devices configuration.


- **NMK key (Network Management Key):** Key set by the user and allows creation of different data networks named AVLN. This 128bit hexadecimal key, is generated based on the Network Password field value using a hash algorithm. NMK key determines whether a slave can connect to a master or not and only devices with the same NMK can be connected together.
- **NET ID, MDF ID, USR ID:** Description fields determining the network name, Televes product description and user description, done by the installer. Installer can change descriptions that make sense in the coaxial network as the location of the modem, its role in the network or who is using it.
- **MDU mode:** Indicates whether MDU mode is active or not.
- **CCo mode (Central coordinator):** CCo is responsible for coordinating communications between devices. In MDU, a CCo is always a master, in HomeNetworking is determined randomly formed networks, not always the same, and all devices can communicate with each other.

EN

MDU Configuration

Sets operating mode of the device.

- **Home Networking:** This is default mode setting at the factory and allows the creation of a local area network where all devices communicate with each other. These networks are usually created when the modem is used to extend internet services within a house. Default mode that is retrieved using the Defaults button.
- **MDU/MTU (Multi-Dwelling/Multi-Tenant Unit).** This mode uses current coaxial network on a building or house to communicate from the headend with each of modems installed on coaxial outlets, providing access to multiple dwellings without can communicate with each other. In this mode have two modes, master and slave.



If you select MDU option is necessary to specify which mode you want:


- **Master:** CoaxDATA operate in master mode and is typically installed in the headend, as described in CoaxDATA product manual. Master controls when the slaves can access the medium synchronizing transmissions and avoiding slave conflicts.
- **Slave:** modem will be installed in a coaxial outlet, as indicated in CoaxDATA product manual.

Select Transmission medium

Sets device transmission medium

- **Hybrid Coax+PLC:** This option indicates that operation mode is hybrid, where devices communicate via PLC and Coax. The **medium switch** on front of device **must be on the left** and power LED is set to **orange color**.
- **Only Coax:** In this mode of operation only coaxial is used as communication medium. The **medium switch** on front of device **must be on the right** and power LED is set to **green color**.
- **Enable Hidden Node:** This option changes medium access mechanism of the devices. Typically medium access method is based on CSMA (carrier sense medium access) listening and checking medium is available. Devices access to medium when no one else is transmitting. This mechanism, however, requires that all of the devices can listen all transmissions of other devices connected to the network. Depending on the coaxial network in which the system is implemented, there may not listen slaves of other slaves transmissions due to a high isolation of distribution outlets ($> 100\text{dB}$) and CSMA access mechanism in not valid.

EN



Enable Hidden Node option replaces medium access contention for a token-based system, where slaves transmit only when the master gives them permission. For this mechanism to work properly, all devices on the network must have this feature enabled.

With this feature modems access to the medium only when they have permission to do so, providing better performance in environments where the insulation between slaves is very high. Since the devices have to get the token for access to the medium, there is a 20% reduction in the total throughput system.

This feature is enabled by default when user select Coaxial Medium to transmit. Disable only when isolation between slaves is a known low value.

Transmission Mask

This option allows setting the transmission mask to use:

- **Mask 0, Hybrid Mask:** This mask transmission is set by default when it is being used in HomeNetworking. Signal starts in very low frequency (2Mhz) to assure transmission on power line network.
- **Mask 1, Sólo Coaxial:** This Transmission mask is used in Coaxial Only mode, the signal starts at a higher frequency (7.5 MHz instead of 2Mhz) avoiding the possible degradation of the communication by using very low frequencies (2 to 7.5 Mhz): noise produced by power switching sources, ground earth on installation, etc...
This mask is used on coaxial transmission at CoaxDATA Ref.200Mbps ref.7689 and ref.768973. It is similar to the Mask 3 and no spectral difference, only provided for compatibility between different CoaxDATA 200Mbps and 1Gbps products and different firmware versions.
- **Mask 3, Sólo Coaxial:** Transmission mask used in Coaxial Only mode, the signal starts at a higher frequency (7.5 MHz instead of 2Mhz) avoiding the possible degradation of the communication by using very low frequencies (2 to 7.5 Mhz): noise produced by power switching sources, ground earth on installation, etc...
This transmission mask is used by default on CoaxDATA 1Gbps devices like refs 769201, 769202 and 769203.

Frequencies Range used by different transmission masks depend on the product being used

	Mask 0 Hybrid	Mask 1 Only Coax	Mask 3 Only Coax
CoaxDATA 200Mbps Ref.7689, 768973	2-30Mhz	7,5-30Mhz	7,5-30Mhz
CoaxDATA 1Gbps Ref.769201, 769202, 769203	2-67,5Mhz	7,5-67,5Mhz	7,5-67,5Mhz

Network Password, Create an AVLN Network

This option allows you to set the network key (NMK) devices. All devices that want to communicate within the same network need the same key NMK. Network set up multiple devices with same key are called AVLN (HomePlug AV Logical Networks) .

NMK is a 128-bit Hexadecimal value, in order to generate valid NMK in a easy way, Network Password on CoaxManager provide a text passphrase, which through a hash algorithm, generate necessary NMK. The passphrase must be entered without any spaces.




Default Network Password is "HomePlugAV" which generate NMK key 50:D3:E4:93:3F:85:5B:70:40:78:4D:F8:15:AA:8D:B7(HomePlugAV).

Network key also defines various networks established in a coaxial network called AVLN (Associated Logical Virtual Network). It is possible to set up four masters simultaneously in a coaxial network.

If user enters a different network key that default, HomePlugAV, next time you connect to device for safety CoaxManager prompted the introduction of it.

Be careful and don't forget the password to connect with devices later.



In case you have forgotten the password, you have a button on the front of the device called **Factory Defaults Button** that allows the device restored to factory settings and reset network key as the default key, HomePlugAV.

EN

User Description

Description that user wants to assign to the device. Descriptions can be set to what makes sense for the installation and the location of the modem, its role in the network or the user who is using it.

Writing Device Settings

Once the user has configured CoaxDATA modem with the appropriate values, **Write Config Button** write configuration on device. Configuration is stored in a memory area dedicated to **user settings**.

If you have issues about setting up or want to delete, Press Factory Default Button to restore the device to the factory, eliminating user settings.




When writing the configuration to a remote device connected through the coaxial, be careful if you change the network key, Network Password, since when change key, change network membership and can not reconnect to device remotely.

By changing the network key loses connectivity via coaxial and reconfigure device will have to do well locally, connecting in the place where it is installed, or set as network key local device the same as the remote device. The same also applies if you change the transmission mask or MxU master/slave mode.

Checking Devices Network

CoaxManager can check data network created with tab named Network that allows you to view the network information associated with a device and other devices as part of the same AVLN (Associated Logical Virtual Network), ie, the devices they have been programmed with the same Network password.



EN

Device Info

Parameters shown in Device Info:

- **MAC:** MAC address of the device that we have connected.
- **TEI** (Terminal equipment identifier): Is an unique identifier of a device on a network. It can accommodate values from 1 (master) to 253 (slaves) MxU mode, and up to 64 slaves on HomeNetworking mode.
- **Hosts Info:** List of different users who have connected to the device from its Ethernet interface.
- **Ethernet Link:** Indicates if any of the two Ethernet interfaces of the device is connected. If is On, this field indicates that the device has someone connected via Ethernet.
- **Get Counters:** This button allows access to the information packets transmitted by the device. The counters displayed are those associated with the coaxial transmission protocol not Ethernet packet count, so these counters are not suitable to measure the traffic sent by a user, and only used for informative purposes.

CCO Info

Parameters shown in CCo Info:

- **CCo MAC:** MAC address of the device with CCo functions (Central Coordinator) on the network. On MxU, displays MAC Address of network master.
- **CCo TEI** (Terminal equipment identifier): Is an unique identifier of a device on a network. It is always 1
- **NID** (Network identifier): When a master proceeds to create new networks on coaxial data generated Network identifiers value by a hash algorithm. In same network can coexists up to 4 masters with same Network Password, creating same AVLN, but with a different NID Identifier. A slave may choose to connect to a master NID or with other, depending on channel conditions.
- **SNID** (Short Network identifier): Value derived from the NID but a single byte. This value is used by slaves to uniquely identify the master who joined to form a network.

EN




Network Topology

This section contains information related to network modems. When the application is connected to the master shows the links established with the slaves.

When device has link set but none devices connected to Ethernet ports show a MAC Bridge = FF: FF: FF: FF: FF: FF and displays a estimate of the channel's bandwidth with three colours green, orange or red.


When device have Ethernet hosts and really there is a flow of information between the master and a slave, you will see information on the channel coding (Mbps) in the columns for TXCoded / Raw (Mbps) and RXCoded / Raw (Mbps), which indicate rates maximum reached by the channel coding on each of the links.

Attenuation conditions, channel noise or zero frequency response can alter the values obtained for throughput. To make more intuitive analysis of the values in the application has chosen a range of colors to indicate the status of the channel

	Indicates that the link operates at maximum rate	coaxDATA 200Mbps-HDTV (120Mbps<throughput<150Mps) coaxDATA 1Gbps-HDTV (300Mbps<throughput<450Mps)
	Indicates that the link operates at medium rate	coaxDATA 200Mbps-HDTV (70Mbps<throughput<120Mps) coaxDATA 1Gbps-HDTV (170Mbps<throughput<300Mps)
	Indicates that the link operates at poor rate	coaxDATA 200Mbps-HDTV (throughput<70Mps) coaxDATA 1Gbps-HDTV (throughput<170Mps)

CoaxManager also provide data about the link tonemap (set of carriers with QAM 4096, QAM 1024, QAM 256,..., QPSK) and transmission mask, which indicates whether the carriers are attenuated or transmitting.

By clicking directly on the link you will get the following window with all the data on it. This information allows to know in addition to providing the link information about frequencies where, by excessive noise or channel attenuations, are decreased their rate tonemap and each of the carriers contributing to the data stream.



EN

- **Source and Destination MAC:** MAC Address of devices that make up the link.
- **TX Rate Coded/PHY y RX Rate Coded/PHY (Mbps):** Estimated Channel rate, for both transmission and reception.
- **Avg.SNR:** Average SNR estimation of received signal
- **Avg.Attenuation:** Average attenuation of the signal in the transmission network.

Generating traffic to verify network links

Some of the information associated with the devices are shown only in the event that there is effective transmissions between two devices. If a device is not connected to any PC, STB or other devices, Generate Traffic button allows virtual generation of traffic between connected device and remote devices that are part of the network.




This feature is only available when connected locally to a device through an Ethernet cable, but is not available when CoaxManager connect to a remote device.

Once the traffic generated between all links, the application displays a message indicating packet generation is over. With this option we can get an estimate of channel between devices without any active hosts on devices, this is useful to check the links at the time of installation of apartment buildings, hotels, etc. ...




The duration of the traffic generation is proportional to the number of devices that form the data network.





Generating Reports for Checking Network State


The application can generate reports containing all the information concerning the status of the network. These reports allow you to export information generated by the application in PDF for later review.

The **Generate Report Button** automatically generates the PDF report  :

Make Report




Once generated PDF report, you can save a compressed (tgz) that contains all the information captured from the network and can be analyzed later.



EN

Setting QoS parameters (Advanced User)

This tab allows configuration of the QoS parameters of a device.



CoaxDATA devices have various QoS mechanisms that allow prioritize traffic by type: either video, voice or data. Each one of these traffic can have, depending on the installation requirements and provide different mechanisms for ensuring priority.

You can set up to 4 priority levels, called CAP "Channel Access Priority": CAP3 (highest priority), CAP2, CAP1 and CAP0 (lowest priority). Packets belonging to higher priority are transmitted first.



There are three mechanisms for priority setting. Are shown in order of preference in the firmware.

- Default Priorities
- Mapping as 802.1p and / or couch
- QoS Rules (CoaxManagerPro Only)

Default Priorities

This section allows the assignment of priority levels based on packets by type. This assignment overrides VLAN tag (802.1p) or IPv4 ToS (Type of Service) priority settings:


- ◆ **Unicast** (default CAP1): sets the default priority for unicast packets without VLAN tag transmitted between devices
- ◆ **IGMP** (default CAP3): Permite asignar la prioridad de paquetes IGMP utilizados para gestionar streams multicast.

- ◆ **Multicast** (default CAP1): Prioridad asignada a streams multicast que no son gestionados por IGMP; es decir, aquellos streams multicast para los cuales no se han generados IGMP reports ni existen IGMP queries que los gestionen.
- ◆ **Multicast gestionados por IGMP** (default CAP3): Prioridad asignada a streams multicast que han sido gestionados por los dispositivos mediante IGMP Snooping.

Priority Levels Assignment

Packets can be assigned to the desired priority level based on:

- **VLAN 802.1P Priority:** VLAN tags are small data field in 802.1 Ethernet packets and determines or specifies the packet type in question. This tag is normally assigned at source or switches established by the network depending on the input port (or any other parameter: multicast, UDP. Destination port, etc). You can set the "User Priority" Tag VLAN 802.1P priority levels CAP0-CAP3.



- **IP Traffic Class:** Priority based on ToS (Type of Service) of IP packets. RFC 1349 describes this field and values like delay, rate optimization or reliability. You can assign one of four priority levels CAP0-3 device according to the first 3 bits of the ToS field (ToS Precedence).

4	4	8	16	16	3	13	8	8	16	32	32		
VERS	HLEN	TOS	Total Length	ID	Flags	Frag Offset	TTL	Protocol	Header Checksum	SA	DA	IP Options	Data

IPv4 HEADER

TTL - Time to Live

CoaxDATA devices allow you to specify a parameter called TTL (Time to Live) for each priority level, CAP. This parameter indicates how long a packet can stay in the buffers (SDRAM) before exceeding the maximum lifetime. Once established time is out packet is dropped.

The time a packet remains in the device buffers before transmission depends on network traffic conditions, the number of modems that make up the network and its effective occupation, so that the establishment of these values should be account the implementation and the estimated rate of service.

By example, this mechanism is often used in VoIP or Video packets where packet time on buffer is excessive and can be discarded because elapsed time is too late at the receiver and is not necessary for decoding.

TTL values for each priority queue and MME (Management Messages, which are used by the

application management like CoaxManager) can be set. The default values are set as follows:

- CAP0 traffic: 2000 msec (used for TCP data traffic)
- CAP1 traffic: 2000 msec (used for TCP data traffic)
- CAP2 traffic: 300 msec (used for UDP video/music traffic)
- CAP3 traffic: 300 msec (used for VoIP traffic)
- MME traffic: 300 msec (used for Management Messages)



It is recommended not to change TTL values unless you know exactly what you are doing.

EN

Buffer Allocation, Priority Thresholds

This option determines memory size (buffers) for each of the priorities. When buffers are full, packets are dropped based on their priority.

Thresholds determining buffers available for each priority.

Available buffers are managed in terms of a percentage allocated to each CAP. When the percentage of allocated buffers exceeded, lower priority packets are discarded but higher priority is still admitted.

By enabling this option, the packages are stored waiting to be transmitted, but if at any time it exceeds a certain percentage of occupancy, the packet is discarded leaving room for higher priority packets.

example:

Suppose you have the following prioritization:

<u>Assigned Percentage</u>	<u>Total Percentage (accumulative)</u>
CAP 0 and higher = 20%	20 %
CAP 1 and higher = 25%	45 %
CAP 2 and higher = 45%	90 %
CAP 3 = 10%	100 %

At any given time:

- If the total number of buffers used for transmission is less than 20% shall be allowed traffic of all priorities (CAP 0 or better).
- If the total number of buffers used exceeds 45% shall be allowed only packages of higher priority CAP1 (CAP1, CAP2 or CAP 3).
- If the number of occupied buffers is greater than 90% are permitted only packets with higher priority than CAP 2, ..., and so on.



This mechanism allows to safeguard the buffer system, preventing higher priority packages run out space with lower priority waiting to be transmitted.



It is necessary to take into account that if the thresholds for priority are not activated, there will be a single buffer to store packets of all priorities, so when buffer is full packets are discarded regardless of their priority. If you want higher priority packets have a reserved space in the buffer, enable this option.

Bandwidth Limit

EN

The bandwidth limit can set a limit on the total transmitted/received data rate, regardless of the priority assigned to them. This limit is activated only when operating mode is MDU. The minimum value is 64Kbps and maximum 16Mbps in increments of 64 Kbps.

- **Upstream Limit:** Limits the traffic transmitted by a host device, ie , from host (Ethernet) to the coaxial.
- **Downstream Limit:** Limits the traffic received by the Ethernet hosts of device, ie , from the traffic received by the coaxial towards hosts (Ethernet).



Bandwidth limit is a feature that can be used in MDU distributions where the installer wishes to set a limit on the bandwidth used by users, programming limit on slave modems. This option is ignored on Home Networking mode.



Bandwidth limit overrides QoS priority. all packets are dropped if exceed limit, regardless of its priority

Bandwidth Limit with QoS

Bandwidth Limit allows operators/installers configure CoaxDATA™ products so that users can only use a certain bandwidth that have hired. However, this functionality can not preserve established QoS settings for data flows, ie, limit of bandwidth is for all traffic without distinguishing the priority of the packets.

To ensure QoS parameters are preserved even if there is bandwidth limit on devices, a new option named **QoS For Bandwidth Limit** is provided, which allows bandwidth limit setting considering QoS for flows transmitted, thereby providing important quality of service for certain applications such as video or voice transmission.

Bandwidth Limiting

<input checked="" type="checkbox"/> Uplink limit(Kbps)	4096	<input checked="" type="checkbox"/> Downlink limit(Kbps)	10240	<input checked="" type="checkbox"/> Enable QoS for Bandwidth Limit (Only Remote MxU Slaves via Coax)
--	------	--	-------	---

- ◆ **limits the bandwidth used by users**, considering the priority of flows, so that the limit applies taking into account packets priority and those lower priority flows are discarded first.
- ◆ Limitation of bandwidth occurs in the internal switch of device, which provides two output ethernet ports. Therefore **only devices that have an internal switch** allow you to implement this functionality.

Following CoaxDATA™ devices support QoS For Bandwidth Limit

- Ref.7689 CoaxDATA™ 200Mbps-HDTV
- Ref.769201 CoaxDATA™ 1Gbps-HDTV
- Ref.769202 CoaxDATA™ 1Gbps-HDTV with SFP

Following CoaxDATA™ devices do not support QoS For Bandwidth Limit: Bandwidth Limit is applied to all flows regardless their QoS:


- Ref.768973 CoaxDATA™ 200Mbps-HDTV 1xEth
- Ref.769203 CoaxDATA™ 1Gbps-HDTV 1XEth

EN

Setting Advanced Configuration

Following options are available for advanced users with a basic knowledge of networking concepts, configuring devices in a more specific way. If you do not understand any of the concepts presented, do not worry probably not need to know.

Below is a screenshot of the application for advanced parameters:




IGMP options

IGMP (Internet Group Management Protocol) is a protocol for managing multicast flows and define the devices to receive multicast data stream (video, audio, etc. ..). IGMP may save bandwidth, indicating devices want to receive a given flow preventing traffic reaches the devices are not interested in the data stream.

CoaxManager provides options to define the behavior of the device on the IGMP protocol. The system supports both IGMPv2 and IGMPv3.

IGMP defines a set of messages to set up multicast network:

- **IGMP join:** Message sent by a device or set-top box that wants to join a multicast group.
- **IGMP leave:** Message sent by a device or set-top box that wants to leave a multicast group.
- **IGMP Querier (Only IGMPv3):** IGMP querier is a IGMP function that implements a Query message (usually Multicast Routers and Switches) where the network periodically ask if anyone is joined to a multicast group. Devices members of multicast channels respond with IGMP message indicating which groups are connected. IGMP Querier can send request for all multicast groups or requests for each managed multicast.



To ensure membership of multicast channels and that information is as updated as possible, and thus prevent a user leaves a channel waste bandwidth, in the IGMP protocol timers are defined:

- **Group Specific Queries Timeout (Only IGMPv3):** This timer expires after 260 seconds where no IGMP Queries sent to a specific group that has been registered in the device. A registered group is one in which there are set-top boxes that indicate their membership of a particular group responding to IGMP queries that are sent periodically by the Multicast Router. If the timer is disabled, once registered multicast flow will not be removed from the table even if no queries made by the Multicast Router.
- **All system Queries Timeout (Only IGMPv3):** This timer expires after 260 seconds where no IGMP Queries sent to all multicasts groups that has been registered in the device. If the timer is disabled, no multicast flow will be removed from the table by expiration timer associated with All System IGMP Query requests.
- **Group Membership Timeout (Only IGMPv3):** This timer controls the period that goes from the transmission of a query to the STB and the lack of response. Delete a stream for which there has been no reply from any STB. If the timer is deactivated the stream will remain active indefinitely.

Normally when a router or switch has no response from a Set-Top Box after several attempts asking about membership in a multicast channel, delete the device joining to the multicast stream, setting a conservative procedure regarding use of bandwidth and causes the master stops transmitting these streams to the coaxial network after expiration of timers.

If you have not installed an IGMP Querier in video distribution, or do not want the streams are eliminated after the expiration, disable timers through the checkboxes in the application.



No purpose of this manual is to define the IGMP protocol or the elements that comprise it. For details refer to the standards defined in this regard: [RFC 1112](#), [RFC 2236](#) IGMPv2 and [RFC 3376](#) IGMPv3



It is recommended not disable timers unless the system do not support IGMPv3 (only support the old IGMPv2). In practice, if disable timers then when device does not indicate that leaves a channel (IGMP leave) by switching channels or disconnected abruptly, he still remains member of channel with the consequent consumption of bandwidth.

EN

Additionally, you can configure a number of parameters associated with IGMP:

- **Forward Unknown/Unmanaged Streams:** All multicast streams are transmitted from the master to the slave even if no one registered in them. Since there is no list of registered devices in each multicast, master uses a very conservative modulation which results in excessive bandwidth consumption. This modulation is named ROBO (ROBust mOdulation) and transmits a maximum of 5Mbps to all devices on network. **It is not recommended to use this option unless you really know what you are doing.**
- **IGMP Reports to Non-Querier Hosts:** By default, IGMP reports only are sent to Ethernet ports if IGMP Querier exists on network, ie, IGMP reports are sent to querier. When this option is enabled allows resend all IGMP join/leaves to Ethernet ports even if IGMP Queriers are not present (ie, Multicast routers or switches connected to the Master). This allows IGMP reports are propagate to network even when no multicast IGMP Queriers exists, but STB periodically send IGMP messages indicated their intention to belong to a specific multicast group.

Although it is possible to implement videostreaming systems that do not require the existence of IGMP Queriers, Installer is recommended to implement an IGMP querier, with a multicast router or a switch, so as to provide an automated management and that guarantees that the bandwidth is used only when users actually want to use video services and releasing those resources when leaving a channel.


Number of Users per Slave

When coaxial data network is implemented in community facilities, is very useful to limit the number of users for each slave, since customers in their homes can use more than one device. This also increases engine performance of the system, since it limits the number of links in the system:

- **MAC Address Limit:** This option sets a limit on the number of hosts connected to MAC Ethernet ports that a device supports. This option can be used by installers of hotels, buildings, who want to limit the number of users who use the data service from the slaves and allows control on the number of total users that will use the data network.
- **Bridge Address Aging:** Set the timer used to determine when an entry in the local table (associated with Ethernet hosts) or a remote table (where hosts are picked from other devices on the network) is invalid or has expired.

Network Mitigation

Normally in a network of one master and several slaves they transmit at maximum power in order to ensure greater coverage and throughput. It is possible that in a coaxial network are installed two different networks, with two masters and their slaves are poorly insulated from each other or the insulation provided by the network is not sufficient and interference occurs between adjacent networks



EN

When several masters coming together or poorly insulated and we form two different networks have the option to control the transmission power and reception sensitivity of the devices on a network to mitigate the effect these have on a network transmissions next and viceversa . This is done by detecting certain packages from nearby networks.

The mitigation Network provides an alternative to the diplexer filter installation for the isolation of data networks. We recommend installation of those filters diplexers so as to isolate the different networks in the coaxial data, see the product manual for more information.

If it is not possible to isolate the networks with filters diplexers, Mitigation Network option allow masters from each of the networks controlling the transmission power of all the elements in order to mitigate the effects that their transmissions have a close network . In the event that this option is not activated, the transmissions of other nearby networks are regarded as transmit interference causing a decrease in the transfer rate between the devices.

Do not use this option in case your installation scheme consists of the installation of multiple masters on the same coaxial distribution (multiple AVLN) and not on separate segments (multiple dwellings)




Keep in mind that the mitigation process is reducing the transmission power of the devices and their sensitivity with consequent loss rate and coverage. This option allows both networks to obtain best rates provided the coverage thereof is not excessive and a decrease in transmission power will not cause a decrease in link quality.



This adjustment process uses an iterative algorithm can have a convergence period of about 17min, so keep this in mind when you restart the device. This period is so long due to the fact that the system must distinguish between noise inherent and/or transients in the transmission line network transmissions causing interference nearby permanent.

Factory Defaults Button

This option allows you to disable the front button that resets the device to factory settings.



Use is limited to cases where the installer wants CoaxManager configuration not be deleted by the client when press the button.

This option increases product security, when disable factory button it is impossible to use it to delete user settings when press.

EN



Although button is disabled, the Factory Default option on CoaxManager through GUI interface is still running and you can set the factory settings by clicking button on application.



Advanced Power Management

This option enables the low power mode on the device, allowing greater energy efficiency. The low power mode is activated when no device connected to the host, or when even if there is connection to PC not transmit data over a long period.

The following table shows the energy savings achieved when activated low power mode

	Power CoaxDATA 200Mbps (Watts)	Power CoaxDATA 1Gbps (Watts)
Normal Working	4.5Watts	6Watts
Low Power Mode	1.8 Watts	1.8 Watts

This option is only available on HomeNetworking mode and firmware versions that support it. In MDU mode this option is not available since some programs like AccessControl™/CoaxManager™ not function correctly when trying to connect to a remote device.

Advanced MME Features

Tab provides options that affect the management protocol that is used to configure the devices CoaxManager named MMEs (Management Messages).

- **Enable VLAN Tag MMEs:** This option enables use of VLAN tags for receiving and sending messages on the device MMEs. Use this option when the operator has a specific VLAN for network management, or when you simply want to use a different VLAN for management. VLAN ID used in responses (MME Response) is the same as that used in the requests (Requests MME). VLAN used on indication messages, messages that emits an informative request (MME Indication), is set on VLAN ID field on GUI.

- **Block Slave MME:** This feature prevents slave sent management requests (MME) to master through coaxial network. It can be activated on slave or master. This option prevents it from the master to slave CoaxManager can connect to and change its configuration, Increasing the safety of the installation.
- **MMEs over Data:** By default, MME messages are transmitted in most robust modulation possible ROBO (Robust Modulation) to ensure coverage in network. This penalizes the system bandwidth as the maximum ROBO mode rate is 5Mbps and intensive management protocol penalizes the bandwidth for use by users. This option allows devices management messages transmitted in the same channels used for data transmission saving bandwidth. Use this option on systems where the channel established between master and slave has good quality.

European technology **Made in  EUrope**